


BELVAR-4




Д-1972, Ш-834, В-865, мм.










L-1972, W-834, H-865, mm.

Інструкція збірки
Assembly instruction


№	довжина(мм) length(mm)	ширина(мм) width(mm)	кількість quantity
1.	1935	795	1
2.	1895	795	1
3.	862**	834*	2
4.	1940*	326	1
5.	1900*	326	1
6.	1940*	170	1
7.	1900*	170	1
8.	500**	834*	2
9.	1940*	150	1




№	довжина(мм) length(mm)	ширина(мм) width(mm)	кількість quantity
10	800	100	2
11	900	115	2
12	870	60	6
13	940**	182**	2
14	868*	132	2
15	500*	132	4
16	900	500	2






1.






 D 3,5x16	x8	 N	x4	 D1 3,5x30	x8	 R	x4
--	----	---	----	---	----	---	----




2.





3.



4.



B1



5. x2

